



Installation Instructions for Pipercross PK026 Ford Escort RS Turbo 1.6

KIT CONTENTS

1. Pipercross power cone.
2. Filter clip.
3. Rain plate.
4. Spacers X 3.
5. Screws X 3.

BEFORE YOU START

1. Please read the instructions before starting work.
2. Disconnect the battery before starting work.
3. Lightly spray the black surface of the filter with the retention additive (where provided) and massage into the foam until full impregnated.

TOOLS REQUIRED

1. 10mm Socket.
2. Flat screwdriver.
3. Phillips screwdriver.

REMOVING THE STANDARD INTAKE

1. Undo three clips (A).
2. Remove the top of the air box (B) and the old air filter.
3. Remove two bolts (C) holding the remainder of the air box to the 'K' jet system and then remove the remainder of the air box.
4. It may feel tight and needs a pull as the rubber neck is a tight fit.

FITTING THE PIPERCROSS INTAKE

1. Fit the filter onto the 'K' jet (1).
2. Tighten the hose clip (2).
3. Oil the filter with the spray oil provided.

FITTING THE RAIN PLATE.

1. Undo three screws holding the original cover (3) to the bonnet (4).
2. Trap three spacers (5) between the rain plate (6) and the original cover (3).
3. Screw with three screws supplied (7) the rain plate (6) to the original cover (3).

AFTER FITTING

1. Reconnect the battery.
2. Start the car and let it idle for 10 minutes.
3. Check for any air leaks.
4. Check for loose fixings.
5. Remove the plastic protective cover from the end of the filter.

Pipercross Filters, Filtration House, Units B/C Longman Court
8 Sketty Close, Brackmills, Northampton, NN4 7PL

Tel: 01604 707750 Fax: 01604 707751 Web: www.pipercross.com Email: sales@pipercross.com